

DOSKO

M2961000D

MODEL NUMBER: 2961000, 2961010,

2961020, 2961060

SERIAL NUMBER: __

Owner's Manual

Instructions for Operation, Maintenance

Stump and Root Grinder

2961000 (337-13H) 2961010 (357-13HE) 2961020 (620-20HE) 2961060 (620-25KE)

Your Dosko grinder is intended for outdoor-use only and can be used to remove many tree stumps and exposed root systems close to ground level. By moving the blade in sweeping movements laterally over the top and front of the stump, you can gradually grind it away. Make sure you completely read and understand this manual before using the grinder for the first time.

AWARNING

READ and UNDERSTAND this manual completely before using the grinder! Failure to properly operate, and maintain this grinder could result in *serious injury or death* to the operator or bystanders.

All machines have hazards associated with their operation. This stump grinder has certain special hazards, which you must be aware of. As an operator or owner you have a duty to be aware of these hazards and know preventive measures to take to avoid them. When reading this manual pay particular attention to avoiding these hazards.

In particular, be aware of the following:

- Know location of buried electrical and other utility lines.
- Do not allow children or untrained adults to operate.
- Wear eye protection and other personal protection against flying rocks and debris.
- Check that cutter wheel teeth are secured, sharp and not missing.
- Do not operate if operator presence bar fails to stop engine upon release.
- Make sure no children or bystanders are within 75' (feet) of stump grinding operation.
- Protect cars, windows and other objects within 75' from flying debris.
- Be prepared for machine "kickback" when initially contacting the stump.
- Be aware of potential for carbon monoxide (CO) poisoning.
- Prevent fires/explosions from fueling.
- Do not attempt to perform adjustments, declog or clean unit while engine is running.
- Avoid burns from engine or hot exhaust.
- Avoid using in wet or icy conditions where falls may occur.

Details about these hazards are found throughout the manual and are summarized at the end of the manual under "Important Safety Information."

STOP!


ADD ENGINE OIL: Your stump grinder comes fully assembled and requires only that you <u>add engine oil to crankcase</u> and fuel to tank.

INSPECT COMPONENTS: Closely inspect to make sure no components are missing or damaged. See the "Receiving Your Unit" section for instructions on whom to contact to report missing or damaged parts.

Any Questions, Comments, Problems, or Parts Orders Call your dealer or Dosko Customer Service 1-800-822-0295



M2961000 Exploded View – Rev D





M2961000 Parts List – Rev D

Item	Part #	Description	Qty	Model	Item	Part #	Description	Qty	Model
1	601091	GX390 Honda	1	2961000	32	777799	Wheel	1	All
	601092	GX390 Estart Honda		2961010	33	783550	End flap	1	All
	783896	GX630 Honda		2961020	34	783556	Pillow block bearing	2	All
	784704	25hp Kohler		2961060	35	783551	Chute flap	1	All
2	785692	Muffler	1	2961020	36	783555	Lo-pro pocket bolt	8	All
2	784059	Muffler canister	1	2961060			500 series straight		2961000
3	785138	Handle	1	All	27	784165	pocket		2961010
4	783924	Spring	1	All	37	704166	700 series straight	4	2961020
_	783493	Operator presence	1	All		784166	pocket		2961060
5	183493	handle bar	1	All		702557	•		2961000
6	782399	Ball joint rod	1	All	20	783557	500 series tooth		2961010
7	783945	Linkage	1	All	38	702550	700 :	8	2961020
8	784207	Throttle cable	1	2961020		783558	700 series tooth		2961060
0	783545	Microswitch	1	A 11	39	783480	Cutter wheel, 14"	1	All
9	783769	Microswitch bracket	1	All			500 series angled		2961000
10	786073 786074 783546	On/off switch w/ black knob	1	2961000	4.0	783554 783559	pocket	4	2961010
				2961010	40		700 series angled		2961020
				2961020			pocket		2961060
				2961060	41	785079	Cutter shaft	1	All
11	783285	8" Lead wire, green	1	2961000			- Frame	1	2961000
				2961010		783435			2961010
				2961020	42	-0.40.44			2961020
				2961020		784041			2961060
12	783284	6" Lead wire, green	1	2961060					2961020
13	783539	2" Spring	1	All	43	784050	Fuel tank and cap	1	2961060
14	783774	4" Hitch pin	1	All					2961020
15	783538	Lock collar	2	All	45	777834	1/4" Hose clamp	4	2961060
16	783815	Black vinyl cap	1	All					2961020
17	784208	Choke cable	1	2961020	46	777345	1/4" Fuel hose	4.17'	2961060
18	32839	43" Battery cable (red)	1	All	48	783484	Wheel & brake drum	1	All
19	777108	24" Battery cable (blk)	1	All	49	783570	Cable clamp	1	All
20	82140	Cotter pin	2	All	50	783567	4" Brake band	1	All
21	124A	Dust cap	2	All	51	783569	1.5" Spring	1	All
22	785134	Inner belt guard	1	All	52	783295	Brake cable	1	All
23	783563	Bushing, 1"	- 1	2961000	53	785128	Battery box	1	All
				2961000	54	783481	Pivot bar	1	All
				2961010	55	785130		1	All
				2961020	33	783130	Battery box top	1	
24	82143	1/4" x 1-3/4" key	1	All		786072	Wine Hemone		2961000 2961010
25	785136	Outer belt guard	1	All	56	780072	Wire Harness	1	2961010
23	783130	Outer beit guard	1	2961000		783283			2961020
26	783562 784052	3" Sheave, 3 groove	1	2961000	57		D.,,1., 1,,,,h1.,	1	
					57	783547	Brake lever assembly	1	All
		3.35" Sheave,		2961020	58	82143	1/4" x 1-3/4" key	1	2961060
27	702552	4 groove	2	2961060	59	783568	Floating pin	2	All
27	783552	Idler bearing	2	All	60	783543	Dosko decal	1	All
	783561	Belt, 3 groove		2961000	61	783544	Stump grinder decal	1	All
28	784056	Belt, 4 groove	1	2961010	62	783212	1/4" x 1/4" hb elbow	2	2961020
				2961020		703212	1/7 A 1/4 HU CHOW	۷	2961060
				2961060	63	781922	Carbon canister	1	2961020
29	783564 784054	4.75" Sheave,	1	2961000	0.5	784769	Sealed fuel cap	1	2961060
		3 groove		2961010	64			1	2961020
		4.75" Sheave,		2961020					2961060
		4 groove		2961060	65	785755	3/8" fuel line	6'	2961020
30	783565	Bushing, 1-3/16"	1	All	66	30745	3/8" hose clamp	2	2961020
31	783790	3/4" Slotted nut	2	All	67	782319	Purge port cap	1	2961060
					68	785411	Air cleaner for GX630	1	2961020
				·		•			